

Connected Home Hub GTW100ZB



[All product documentation](#)



en	Installation instructions
cs	Návod k instalaci
el	Οδηγίες εγκατάστασης
fi	Asennusohjeet
hu	Telepítési utasítások
nl	Installatie-instructies
pt	Instruções de instalação
ru	Инструкции по установке
sv	Installationsanvisningar
zh-CN	安装指南

de	Montageanleitung
da	Installationsanvisninger
es	Instrucciones de instalación
fr	Instructions d'installation
it	Istruzioni per l'installazione
pl	Instrukcja montażu
ro	Instrucțiuni de instalare
sk	Návod na inštaláciu
tr	Kurulum talimatları
zh-TW	安裝指南

Dimensions:

- Width: 92.0 mm
- Height: 92.3 mm
- Depth: 37.2 mm

Connections:

- LAN1, LAN2 (Ethernet)
- DC IN (Power)
- Power Adapter

Mobile app

More info about LED

Front Panel Callouts:

- Power button
- LED 1
- LED 2
- LED 3
- LED 4
- Circular indicator

en		de		cs	
1	Power LED	1	Power-LED	1	LED dioda pro napájení
2	Ethernet LED	2	Ethernet-LED	2	LED dioda pro Ethernet
3	WLAN LED	3	WLAN-LED	3	LED dioda pro WLAN
4	Zigbee LED	4	ZigBee-LED	4	LED dioda pro Zigbee
5	Factory reset hole	5	Öffnung für Werksreset	5	Otvor pro obnovení továrního nastavení
6	Restart / Binding button	6	Taste Neustart / Binding	6	Tlačítko pro restartování / vazbu
da		el		es	
1	Power LED	1	Φωτοδίοδοι ηλεκτρικής ισχύος [Power LED]	1	LED de encendido
2	Ethernet LED	2	Ethernet LED	2	LED de Ethernet
3	WLAN LED	3	WLAN LED	3	LED de wifi
4	Zigbee LED	4	Zigbee LED	4	LED de Zigbee
5	Hul til nulstilling til	5	Οπή επαναφοράς εργοστασιακών	5	Orificio de restablecimiento de fábrica
6	Genstarts- / Binding-knap	6	Επανεκκίνηση / Κουμπί σύνδεσης	6	Botón de reinicio / vinculación
fi		fr		hu	
1	Virta-LED	1	Voyant LED d'alimentation	1	Tápellátás LED
2	Ethernet-LED	2	Voyant LED Ethernet	2	Ethernet LED
3	WLAN LED	3	Voyant LED WLAN	3	WLAN LED
4	ZigBee-LED	4	Voyant LED Zigbee	4	Zigbee LED
5	Tehtaan nollausaukko	5	Orifice de réinitialisation aux	5	Gyári visszaállítás furat
6	Uudelleenkäynnistys / Yhdistyspainike	6	Bouton Redémarrer / Connexion	6	Újraindítás / Kötés gomb
it		nl		pl	
1	LED di alimentazione	1	Stroom-ledlampje	1	Dioda zasilania
2	LED Ethernet	2	Ethernet-ledlampje	2	Dioda Ethernet
3	LED WLAN	3	WLAN-ledlampje	3	Dioda WLAN
4	LED Zigbee	4	Zigbee-ledlampje	4	Dioda ZigBee
5	Foro reset di fabbrica	5	Gaatje voor reset naar	5	Otwór przycisku przywracania ustawień
6	Pulsante Riavvia / Rilegatura	6	Toets voor herstart / binding	6	Przycisk restartu / powiązania
pt		ro		ru	
1	LED de energia	1	LED de alimentare	1	Светодиод питания
2	LED Ethernet	2	LED Ethernet	2	Светодиод Ethernet
3	LED WLAN	3	LED WLAN	3	Светодиод WLAN
4	LED Zigbee	4	LED Zigbee	4	Светодиод Zigbee
5	Orifício de reposição dos valores de fábrica	5	Orificiu de resetare din fabrică	5	Отверстие для сброса к заводским настройкам
6	Botão Reiniciar / Ligar	6	Buton Repornire / Legătură	6	Кнопка перезапуска / привязки
sk		sv		tr	
1	LED napájanía	1	LED för ström	1	Güç LED'i
2	LED ethernet	2	LED för Ethernet	2	Ethernet LED'i
3	LED WLAN	3	LED för WLAN	3	WLAN LED'i
4	LED Zigbee	4	LED för Zigbee	4	Zigbee LED'i
5	Otvor na obnovenie výrobných nastavení	5	Hål för fabriksåterställning	5	Fabrika ayarlarına sıfırlama deliği
6	Tlačítko Reštart / prepojenie	6	Knapp för omstart / bindning	6	Yeniden başlatma / Bağlama düğmesi
zh-CN		zh-TW			
1	电源指示灯	1	電源指示燈		
2	以太网指示灯	2	乙太網指示燈		
3	WLAN 指示灯	3	WLAN 指示燈		
4	Zigbee 指示灯	4	Zigbee 指示燈		
5	出厂设置复位孔	5	原廠設定復位孔		
6	重启/绑定按钮	6	重啟/繫結按鈕		