



Connected Home Thermostat wired Connected Home Thermostat wireless



[All documentation](#)


RDZ100ZB
RDZ101ZB

| | |
|--------------|--------------------------|
| en | Mounting instructions |
| cs | Návod k montáži |
| el | Οδηγίες τοποθέτησης |
| fi | Asennusohje |
| hu | Telepítési leírás |
| nl | Montage-aanwijzing |
| pt | Instruções de instalação |
| ru | Инструкция по установке |
| sv | Monteringsinstruktion |
| zh-CN | 安装指南 |


| | |
|--------------|--------------------------|
| de | Montageanleitung |
| da | Monteringsvejledning |
| es | Instrucciones de montaje |
| fr | Instructions de montage |
| it | Istruzioni di montaggio |
| pl | Instrukcja montażu |
| ro | Instructiuni de montaj |
| sk | Návod na montáž |
| tr | Montaj talimatları |
| zh-TW | 安裝指南 |



RDZ100ZB/RDZ101ZB




RDZ100ZB




RDZ101ZB


1a




1b




2




3a




3b




4



5




6




RDZ100ZB/RDZ101ZB


1




2



3



4



RDZ100ZB only

